

DETAIL "E" BANK END HARDWARE

USE 18" LONG CORNER 1.5" DEEP UNISTRUT (DRILLED NOT SLOTTED) AT CORNERS OF COLLECTOR BANK (TO SUPPORT FITTINGS). USE TEES AND ELBOW TO JOIN POWERSTRIP HEADER MANIFOLD RUNS.



MAKE CONNECTION TO P4100 MAIN MEMBER USING 3/8X1" PLATED BOLTS, HD GALVANIZED WASHERS AND UNISTRUT NUTS. SAME CONNECTIONS AT ROOF CONNECTIONS EVERY 4 FEET

P4100 SLOTTED UNISTRUT USED PARALLEL TO PSG135 HEADERS.

HOT SUN INDUSTRIES LTD. Burnaby BC Canada 778-300-1803		LOW PITCH SIDEWAYS MOUNTING	
		UNISTRUT CORNER ASSEMBLY POWERSTRIP PSG135 SOLAR COLLECTORS	
ECH/SC		NO. DESSIN / DWG NO.	GR/SIZE
DATE	Sept 29, 2012	DWG SS 1300-E	
PAR/BY	KEN WRIGHT		
VER/CHK			